

Intelligent Analysis of Biomedical Images HW1

lachin.naghashyar - 98110179

October 2023

Q1.1

If $y[n] = x[n] * h[n]$, then $y[n-1] = x[n-1] * h[n-1]$?

S1.1

Given the convolution:

$$y[n] = x[n] * h[n]$$

This means that $y[n]$ is the convolution of $x[n]$ and $h[n]$. The convolution is defined as:

$$y[n] = \sum_{k=-\infty}^{\infty} x[k] \cdot h[n-k]$$

For the value $y[n-1]$ based on the given convolution relationship:

$$y[n-1] = \sum_{k=-\infty}^{\infty} x[k] \cdot h[n-1-k]$$

This is not equal to $x[n-1] * h[n-1]$ since $x[n-1]$ and $h[n-1]$ are just single values at $n-1$, not entire sequences.

Q1.2

If $y(t) = x(t) * h(t)$, then $y(-t) = x(-t) * h(-t)$

S1.2

Given

$$y(t) = x(t) * h(t)$$

the convolution integral for continuous-time signals is:

$$(x * h)(t) = \int_{-\infty}^{\infty} x(\tau) \cdot h(t - \tau) d\tau$$

Evaluating at $-t$:

$$y(-t) = \int_{-\infty}^{\infty} x(\tau) \cdot h(-t - \tau) d\tau$$

This is not the same as $x(-t) * h(-t)$. The expression $x(-t) * h(-t)$ represents the convolution of the time-reversed versions of $x(t)$ and $h(t)$. It's a different operation than simply evaluating $y(t)$ at $-t$.

Q2

Given two LTI systems. S_1 has input x and output w . S_2 has input w and output y . The systems are causal and described by the following difference equations:

$$S_1 : w[n] = \frac{1}{2}w[n-1] + x[n]$$

$$S_2 : y[n] = \alpha y[n-1] + \beta w[n]$$

Given:

$$y[n] = \left(-\frac{1}{8}\right)y[n-2] + \frac{3}{4}y[n-1] + x[n]$$

Find the values of α and β .

S2.1

The impulse response of a cascade connection of two systems is given by the convolution of their individual impulse responses. Let the impulse response of system S_1 be $h_1[n]$ and that of system S_2 be $h_2[n]$.

The impulse response $h[n]$ of the cascade connection is:

$$h[n] = h_1[n] * h_2[n]$$

which is computed using the convolution sum:

$$h[n] = \sum_{k=-\infty}^{\infty} h_1[k] \cdot h_2[n-k]$$

Given the previously computed values of $h_1[n]$ and $h_2[n]$:

$$h_1[0] = 1, \quad h_1[1] = 0.5, \quad h_1[2] = 0.25 \quad (\text{and } h_1[n] = 0 \text{ for } n > 2)$$

$$h_2[0] = 1, \quad h_2[1] = 0.25, \quad h_2[2] = 0.0625 \quad (\text{with values halving for } n > 2)$$

Using the convolution sum, we find the impulse response $h[n]$ for the cascade connection:

$$h[0] = 1, \quad h[1] = 0.75, \quad h[2] = 0.4375, \quad h[3] = 0.09375, \quad h[4] = 0.015625$$

These values represent the impulse response for the cascade connection of the systems S_1 and S_2 . Subsequent values of $h[n]$ will quickly approach zero.

S2.2

The impulse response of the cascade connection of two systems is the convolution of their individual impulse responses. Given the impulse responses of systems S_1 and S_2 :

$$h_1[0] = 1, \quad h_1[1] = 0.5, \quad h_1[2] = 0.25 \quad (h_1[n] = 0 \text{ for } n > 2)$$

$$h_2[0] = 1, \quad h_2[1] = 0.25, \quad h_2[2] = 0.0625 \quad (h_2[n] \text{ values halve for } n > 2)$$

The impulse response $h[n]$ of the cascade connection can be computed as:

$$h[n] = \sum_{k=-\infty}^{\infty} h_1[k] \cdot h_2[n-k]$$

Computing the convolution for the first few terms, we get:

$$\begin{aligned}
h[0] &= 1 \\
h[1] &= 0.75 \\
h[2] &= 0.4375 \\
h[3] &= 0.09375 \\
h[4] &= 0.015625
\end{aligned}$$

S4.1

Given the convolution:

$$(x * y)[m, n] = \sum_{m'=0}^{N-1} \sum_{n'=0}^{N-1} x[m', n'] \cdot y[m - m', n - n']$$

For each fixed pair (m, n) :

1. You iterate over all m' values from 0 to $N - 1$. This requires N operations. 2. For each m' , you iterate over all n' values from 0 to $N - 1$. This requires N operations. 3. Thus, for each m' , the inner summation requires N operations. Since there are N possible values of m' , the total operations for a fixed (m, n) is N^2 .

Now, you have to perform this for every possible pair (m, n) , and since there are $N \times N$ such pairs, the total number of operations becomes $(N \times N) \times N^2 = N^4$.

So, the time order of this calculation is $O(N^4)$.

4.2

Yes, we can use the Convolution Theorem which states that convolution in the spatial domain is equivalent to multiplication in the frequency domain.

We can use this theorem as follows; 1. **Fourier Transform**: Compute the 2D Fourier Transform of both images x and y using the Fast Fourier Transform (FFT). ($O(N^2 \log N)$) 2. **Multiplication**: Multiply the two Fourier Transforms element-wise. ($O(N^2)$) 3. **Inverse Fourier Transform**: Compute the Inverse 2D FFT of the product obtained in the previous step to get the convolution result. ($O(N^2 \log N)$).

The overall time complexity for the process is:

$$O(N^2 \log N) + O(N^2) + O(N^2 \log N) = O(N^2 \log N)$$

5.1

DICOM, standing for Digital Imaging and Communications in Medicine, is a pivotal standard in medical imaging. Here's a distilled overview of a DICOM file's characteristics:

1. **Patient Info**: Carries unique identifiers such as name, ID, birth date, and sex.
2. **Medical Context**: Outlines the study, modality (e.g., CT, MR), and specific medical procedure.
3. **Image Content**: Encompasses the actual image, its size, clarity, and visual settings.
4. **Technical Specs**: Includes details of image acquisition, timestamp of creation, and equipment specifics.
5. **Unique Identifiers**: Assigns a unique code to each image, study, or series.
6. **Annotations**: May contain text or visuals on the image for extra context or emphasis.

7. **Supplementary Data:** Can house additional data like ECG patterns or audio notes.
8. **Compression:** Employs data compression for efficient size management and transfer.
9. **Security Measures:** Ensures data confidentiality through anonymization and encryption protocols.

DICOM files are essential for medical imaging for these reasons:

1. **Consistency:** Ensures images look consistent across various devices and software.
2. **All-in-One:** Stores both the patient info and the image together.
3. **Details:** Contains info about the image's origin and method.
4. **Sharing:** Makes it easy to share images between different places.
5. **Notes:** Allows adding direct notes or marks to the image.
6. **Safety:** Keeps patient data secure and private.
7. **More Views:** Supports moving or 3D images, not just flat ones.

Rescale Intercept and **Rescale Slope** are tags in DICOM that help convert the raw pixel values in medical images to values that doctors find more useful.

Rescale Slope Multiplier for the raw pixel value, adjusting its scale.

Rescale Intercept Value added after scaling, shifting the result.

They help us to have:

1. **Uniform Images:** Ensures images from different sources show standardized data.
2. **Precise Readings:** Makes sure the image values are accurate for diagnosis.
3. **Adaptable Storage:** Allows detailed raw data storage, then converts it to doctor-friendly values.
4. **Easy Comparisons:** Helps in comparing or merging images from different machines.

5.2

Anonymizing DICOM files ensures patient privacy while retaining the clinical value of the data. Here's how it's typically done:

1. **Tag Removal:** Erase specific tags holding patient details such as name, ID, and birth date.
2. **Pseudonymization:** Swap identifiers with random codes, preserving data matching without exposing identities.
3. **Date Adjustments:** Modify dates by random intervals to maintain event sequences without revealing actual dates.
4. **Image Alterations:** Mask unique image features, e.g., tattoos.
5. **UID Changes:** Substitute original Unique Identifiers with random ones.
6. **Text Scrubbing:** Cleanse reports or annotations of any identifiable free text.
7. **Activity Logs:** Maintain records of the anonymization changes.

Additional Considerations:

- **Encryption:** Add an extra layer of security by locking the files.
- **Validation:** Post-anonymization, ensure compliance with DICOM standards and confirm the clinical data's integrity.

`pydicom` is a Python library tailored for DICOM file operations. It provides utilities for editing or removing sensitive tags for anonymization.

```
import pydicom
```

```
ds = pydicom.dcmread("file_path.dcm")  # Load DICOM
ds.PatientName = "Anonymous"           # Modify tags
ds.PatientID = ""
# ... other tags as needed
ds.save_as("anonymized_file_path.dcm") # Save changes
```

Key `pydicom` Modules

1. `pydicom.dataset`: Represents the main structure holding DICOM tags and values.
2. `pydicom.dcmread/dcmwrite`: Functions for reading and writing DICOM files.
3. `pydicom.tag`: Manages DICOM tags.
4. `pydicom.dataelem`: Represents individual DICOM data elements.
5. `pydicom.uid`: Handles DICOM Unique Identifiers (UIDs).
6. `pydicom.pixel_data_handlers`: Manages pixel data formats.
7. `pydicom.valuerep`: Ensures proper DICOM value representations.

While `pydicom` offers a straightforward approach to basic anonymization, thorough protection may require combining it with other tools or logic.

In summary, `pydicom` simplifies DICOM operations in Python, but thorough anonymization requires careful consideration.